




DESCRIPTION

The Bryce Hanging Down Light works with AR11 or MR16 lamps.

BRYCE HANGING DOWN LIGHT

Use	Downlighting Techniques in Trees or Architecture by Hanging on a Chain or Cable Brass, Copper, or Brass w/ Black Cerakote*	
Finish		
Includes	LightingShrink Professional Crimp and Heat Shrink Cable Connector	
Order Without	Fits AR11	BRYCE-HDL-AR11-CU-NL
Lamp		BRYCE-HDL-AR11-BR-NL
		BRYCE-HDL-AR11-BR-BLK-NL
	Fits MR16	BRYCE-HDL-MR16-CU-NL
		BRYCE-HDL-MR16-BR-NL
		BRYCE-HDL-MR16-BR-BLK-NL





WILDLIFE LIGHTING CERTIFICATION PROGRAM

Certification Number: 2019-269

Certification Requirements: Amber LED; Must be installed below structures; Allowed on the ground floor only, unless on the landward side of the structure; Additional shielding may be necessary if visible from the beach





Application picture shown as BRYCE-HDL-AR11-CU (not in Amber)

INSTALLING THE LAMP

- 1. Unscrew the fixture body from the base.
- 2. Install the lamp in the socket.
- 3. Reinstall the fixture body.

HANGING THE FIXTURE

IMPORTANT: DO NOT INSTALL ON OR NEAR ANY HIGH VOLTAGE POWER LINES

- 1. Hang the fixture from a secure stainless steel eye bolt, with or without a chain.
- 2. Create a drip loop with the wire by bending the wire to a slope one inch below the fixture cap.

WILDLIFE LIGHTING CERTIFICATION PROGRAM

Certification Number: 2019-269

Certification Requirements: Amber LED; Must be installed below structures; Allowed on the ground floor only, unless on the landward side of the structure; Additional shielding may be necessary if visible from the beach

