

Bluetooth: Preferred Set Up

Use this method to quickly set up a Smart Socket 3.0 device on the Brilliance Smart app via Bluetooth.

Technical Requirements

Must have consistent 2.4 GHz Wi-Fi signal at the installation location with dBm strength of -70 or better.

1. Download Brilliance Smart from the Apple

App Store or Google Play by scanning

the QR code. Register for an account if you are a first time user.



2. In your phone's settings, make sure Bluetooth is turned on.



3. Open the Brilliance Smart app and tap the **Add** button in the upper-right corner.



4. The **Add Manually** tab is displayed and the Bluetooth begins looking for a new device.



 When the device pairs via Bluetooth, the Devices to be Added box is displayed. Tap the Go to Add button.



Set Up continues on the next page

Bluetooth: Preferred Set Up, Continued

6. Enter your 2.4 GHz Wi-Fi information and tap **Next**.



7. The Smart Socket 3 device will automatically start connecting to the app.



8. When the device is connected, tap the **Next** button at the bottom of the screen.

×	
Found 1 devices. Added 1 successfully.	
Smart Socket 3	
Next	
Next	

9. When the device is connected, the Added screen is displayed. Tap the **Pencil icon** to rename the device, then tap **Done** to finish.



NOTE: If Bluetooth Set Up does not connect, try the AP Set Up instructions.